

MAINTENANCE MANUAL

YAMADA AIR-OPERATED DIAPHRAGM PUMPS

**NDP-40
NDP-50
NDP-80**

⚠️ WARNING



- For your own safety, be sure to read these procedures carefully before performing maintenance on this product. After reading this document, be sure to keep it handy for future reference.

This maintenance manual covers what you should know about maintenance of the Yamada NDP-40 series, NDP-50 series and NDP-80 series Diaphragm Pumps.

This edition is based on the standards for the March 2007 production run. Remember, the specifications are always subject to change; therefore, some of the information in this edition may not apply to new specifications.

• Warnings and Cautions

For safe use of this product, be sure to note the following: In this document, warnings and cautions are indicated by symbols. These symbols are for those who will operate this product and for those who will be nearby, for safe operation and for prevention of personal injury and property damage. The following warning and caution symbols have the meanings described below. Be sure to remember their meanings.

⚠️ WARNING : If you ignore the warning described and operate the product in an improper manner, there is danger of serious bodily or property damage.

⚠️ CAUTION : If you ignore the caution described and operate the product in an Improper manner, there is danger of personal injury or property damage.

Furthermore, to indicate the type of danger and damage, the following symbols are also used along with those mentioned above:



This symbol indicates a DON'T, and will be accompanied by an explanation on something you must not do.



This symbol indicates a DO, and will be accompanied by instructions on something you must do in a certain situation.

⚠️ WARNING



- Before starting maintenance work, cut off the feed air and clean the pump. If air pressure or residue remain in the pump, there is danger of explosion, or possible poisoning resulting in serious injury or death if chemicals adhere to the skin or are accidentally swallowed. (For details on cleaning the pump, refer to Chapter 6 of the operating manual.)
- When replacing parts, be sure to use the recommended genuine parts or Equivalents. Use of other parts may cause a malfunction of the product.

⚠️ CAUTION



- When it is instructed that special tools must be used, be sure to use the specified tools. Otherwise, the pump may be damaged.
- Refer to 10.1 "Specifications" in the Operating Manual. Also, remember that the pump is heavy, and extreme care must be taken when lifting it.

Table of Contents

· Warnings and Cautions	
· Table of Contents	
1. Principles of operation	1
2. Tools, etc.	
2.1 General tools	1
2.2 Special tools	1
2.3 Misc.	1
3. Ordering Replacement parts	1
4. Balls and Valve seats	
4.1 Removal	
■ BA□, BS□, BF□ types	2
■ NDP-40 BP□・BV□ type	3
■ NDP-50 BP□・BV□, NDP-80 BP□ types	4
4.2 Inspection	5
4.3 Installation	5
5. Diaphragm and Center rod	
5.1 Removal	
■ BA□, BS□, BF□ types	6
■ BP□, BV□ types	6
5.2 Inspection	7
5.3 Installation	
■ B□C, B□N, B□E, B□V, B□H, B□S types	7
■ B□T types	8
6. Throat bearing and Pilot valve	
6.1 Removal	9
6.2 Inspection	9
6.3 Installation	9
7. C Spool valve assembly	
7.1 Removal	10
7.2 Inspection	11
7.3 Installation	11
8. Retightening of Tie rods	12
9. Exploded View and Parts List	
9.1 NDP-40・50 BA□	13
9.2 NDP-40・50 BS□, BF□	15
9.3 NDP-40 BP□, BV□	17
9.4 NDP-50 BP□, BV□	19
9.5 NDP-80 BA□	21
9.6 NDP-80 BS□, BF□	23
9.7 NDP-80 BP□	25
9.8 COMMON PARTS	27
9.9 BODY ASSEMBLY	29
9.10 VALVE BODY ASSEMBLY	30

4.Balls and Valve seats

4.1 Removal

■BA□, BS□, BF□, types

See [9. Exploded View] on after p. 13. (Fig. 4.1, 4.2 and 4.3 show the NDP-50 BS□.)




Fig.4.1

- Remove the 6 (8 on the NDP-80) retainer bolts 1 from the out manifold, and remove the out manifold. [Fig.4.1]




Fig.4.2

- Remove the ball, valve seat and O ring. [Fig.4.2]




Fig.4.3

- Remove the 6 (8 on the NDP-80) retainer bolts 2 from the in manifold, and remove the in manifold. [Fig.4.1]
- Remove the ball, valve seat and O ring. [Fig.4.3]

■ NDP-40 BP□·BV□ type

See [9. Exploded View] on after p. 13.




Fig.4.4

- Remove the 8 retainer bolts 1 from the out manifold, and remove the out manifold. [Fig.4.4]




Fig.4.5

- Remove the ball, valve seat and O ring. [Fig.4.5]




Fig.4.6

- Remove the 8 retainer bolts 2 from the in manifold, and remove the in manifold. [Fig.4.4]
- Remove the ball, valve seat and O ring. [Fig.4.6]

■ NDP-50 BP□·BV□, NDP-80 BP□ types

See [9. Exploded View] on after p. 13. (Fig. 4.7, 4.8 and 4.9 show the NDP-50 BP□.)




Fig.4.7

- Remove the 6 (8 on the NDP-80) retainer bolts 1 from the out manifold, and remove the protector and out manifold. [Fig.4.7]




Fig.4.8

- Remove the ball, valve guide (only NDP-80), valve seat and O ring. [Fig.4.8]




Fig.4.9


- Remove the 6 (8 on the NDP-80) retainer bolts 2 from the in manifold, and remove the protector and in manifold. [Fig.4.7]
- Remove the ball, valve guide (only NDP-80), valve seat and O ring. [Fig.4.9]

5.Diaphragm and Center rod


5.1 Removal

■BA□, BS□, BF□ types


See [9. Exploded View] on after p. 13. (Fig. 5.1 shows the NDP-50 BS□.)



- Remove the ball and valve seat etc.(see [4.1 Removal BA □, BS□, BF□ types] on p. 2)
- Remove the 16 (24 on the NDP-80) retainer bolts from the out chamber, and remove the out chamber. [Fig.5.1]




- Remove the nuts on both sides of the center rod. [Fig.5.2]
- After the nut on one side have been removed, remove the center disk and diaphragm. Remove the diaphragm, center disk and center rod from the opposite side of the main body.




- Remove the nut on the opposite side using the double nut. [Fig.5.3]
- Remove the coned disk spring, center disk and diaphragm.

■BP□, BV □types

See [9. Exploded View] on after p. 13. (Fig. 5.4 shows the NDP-40 BP□.)



- Remove the ball etc.(see [4.1 Removal BP□, BV□ types] on pp. 3-4)
- Remove the 8 (4 on the NDP-40) retainer bolts from the stand body, and remove the stand body. [Fig.5.4]




- Remove the 16 (24 on the NDP-80) retainer bolts from the out chamber, and remove the out chamber. [Fig.5.5]


6.Throat bearing and Pilot valve assembly

6.1 Removal


See [9. Exploded View] on after p. 13.




- Remove the diaphragm and center rod (see [5.1 Removal] on pp. 6-7).
- Remove the 12 retainer bolts from the air chamber, and remove the air chamber. [Fig.6.1]



- Draw out the pilot valve and valve seat. [Fig.6.2]
- Draw out the throat bearing. [Fig.6.2]



- Remove the packing from the throat bearing. [Fig.6.3]



- Throat bearing [Fig.6.4]
Measure the inside diameter, and if it is outside the usable range, replace the throat bearing


Usable range of throat bearing

$\varnothing 25.04 \sim \varnothing 25.13\text{mm}$

- O rings, Packing
If the O ring is worn out or cracked, replace it.
- Pilot valve
If the pilot valve is worn out or cracked, replace it.

6.3 Installation

For installation, see [9. Exploded View] on after p. 13, and install in the reverse order of disassembly.



Tightening torque for air chamber retainer bolts
 $20 \text{ N}\cdot\text{m} \{ 200\text{kgf}\cdot\text{cm} \}$


<NOTE>

- Make sure there is no dust on the seal surface and the seal is not damaged.
- Apply grease to packing.


7.C spool valve assembly

7.1 Removal


See [9. Exploded View] on after p. 13.




- Remove the out manifold (see 4.1 Removal on pp. 2, 3-4).
- Remove the 6 retainer bolts from the valve body, and remove the valve body. [Fig.7.1]



- Remove the 8 cap A and cap B retainer bolts, and remove cap A and cap B. [Fig.7.2]



- Draw out the C spool valve assembly, and remove the seal ring from the C spool valve assembly.
- Remove the spring stopper. [Fig.7.3]



- Remove the sleeve using the sleeve remover (special tool: Part number 713180). [Fig.7.4]

8. Retightening of Tie rods

- The torque should be applied on the occasion of
 - (1) Right before the pump to use.
 - (2) There are any leaks of material on daily inspecting a pump.




Fig.8.1


<NOTE>

- Tighten the bolts that balance should be equal from both side on diagonal line with even torque.
- Retighten the Out chamber and then the manifold in this order. [Fig.8.1]

9. Exploded View and Parts List


9.1 Exploded View

■ NDP-40 ■ 50BA□




9.2 Exploded View

■ NDP-40 □ 50BS□, BF□




9.3 Exploded View

■ NDP-40BP□, BV□




9.4 Exploded View

■ NDP-50BP□, BV□



9.5 Exploded View

■ NDP-80BA□



9.5 Parts List

■ NDP-80BA□

NO.	BA□	DESCRIPTION	Q'TY	NOTE
1	580962	OUT CHAMBER	2	
2	714370	IN MANIFOLD	1	581050
3	714364	OUT MANIFOLD	1	581047
5	803123	BODY ASSEMBLY	1	
7	711901	CENTER ROD	1	
7T	711940	CENTER ROD	1	
8	711906	CENTER DISK	4	
8T	711041	CENTER DISK	4	
10	Tab.1	DIAPHRAGM	2	
11	Tab.3	VALVE SEAT	4	
12	Tab.4	BALL	4	
14	684324	BALL VALVE	1	3/4"
15	634034	ELBOW	1	3/4"
19	711912	PUMP BASE	2	
20	771402	CUSHION	4	
21	Tab.6	NUT	2	
22	682740	CONED DISK SPRING	2	M16
23	686025	BOLT	20	M10 x 1.5 x 70
24	631014	PLAIN WASHER	4	M10
25	631917	WAVE SPRING WASHER	4	M10
26	611204	BOLT	16	M12 x 1.75 x 55
27	631015	PLAIN WASHER	16	M12
28	631918	WAVE SPRING WASHER	16	M12
29	627014	NUT	16	M12 x 1.75
33	611177	BOLT	4	M10 x 1.5 x 35
34	627013	NUT	4	M10 x 1.5
35	611149	BOLT	4	M8 x 1.25 x 25
36	682276	NUT WITH FLANGE	4	M8 x 1.25
40	Tab.8	O RING	4	
41T	643015	O RING	4	P16 PTFE
42	686026	BOLT	4	M10 x 1.5 x 130
43	634050	ELBOW	1	1"
44	681040	SILENCER	1	1"
50	791071	NAME PLATE	1	
53T	643135	O RING	4	G100 PTFE


NOTE 1)T:BAT

2)Tab.1~Tab.11:SEE [9.8 Parts List "COMMON PARTS"] ON P.27,P.28.

3)NO.50(NAME PLATE) IS NOT INDICATED IN EXPLODED VIEW


9.6 Exploded View

■ NDP-80BS□, BF□




9.7 Exploded View

■ NDP-80BP□



9.10 Exploded View

■ VALVE BODY ASSEMBLY



9.10 Parts List

■ VALVE BODY ASSEMBLY

803120 VALVE BODY ASSEMBLY

NO.	PART NO.	DESCRIPTION	Q'TY	NOTE
5-13-1	711946	VALVE BODY	1	
5-13-2	580999	CAP A	1	
5-13-3	581000	CAP B	1	
5-13-5	771735	SPRING STOPPER	1	
5-13-6	712976	RESET BUTTON	1	
5-13-8	771738	GASKET	2	
5-13-9	685036	HEXAGON SOCKET HEAD BOLT	8	M8 x 1.25 x 20
5-13-12	803115	C SPOOL VALVE ASSEMBLY	1	* ¹ (640036)
5-13-13	640005	O RING	1	P8 NBR
5-13-14	684128	CUSHION	4	

NOTE)*1: PARTS NUMBER MENTIONED ON O RING FOR SLEEVE ASSEMBLY ONLY.

Manufactured by
YAMADA CORPORATION

INTERNATIONAL DEPARTMENT

No.1-3, 1-Chome, Minami- Magome, Ohta-Ku, Tokyo, 143-8504, Japan
PHONE : +81-(0)3-3777-0241
FAX : +81-(0)3-3777-0584

200711 NDP188M